


# SC-SC-SC, 1-volume and 2-tone

1st tone for Neck/Mid and 2nd tone for Bridge



5-way blade switch	
Pos.1	Neck
Pos.2	Neck/Mid
Pos.3	Mid
Pos.4	Mid/Bridge
Pos.5	Bridge